




1. Place your banner on the floor and rotate the feet 90 degrees to the base

2. Place your stand on the floor and take out the pole




3. Unfold the pole and connect the elasticated sections

4. Insert pole into the base slot and secured into the stopper



5. Gently pull up the graphic with your foot stepped on the cassette foot

6. Secure the banner to the head of the pole using the groove



To disassemble:

Carefully unclip the head of the banner from the pole and slowly let the banner retract into the cassette, watching that you don't scrape the vinyl on the sides.